


001 Crankcase



## 001 Crankcase

No.	Part No.	Name	Qty
0	164025	COMPLETE CRANKCASE	1
1	164025	CRANKCASE	1
2	150311	GASKET	2
3	136875/R	CYLINDER LINER	8
3	136875/G	CYLINDER LINER	8
3	136875	CYLINDERS LINER	8
4	136258	GASKET	8
5	148093	NUT	20
6	151117	WASHER	20
7	14325540	THREADED PLUG	3
8	148311	STUD	20
9	13525870	THREADED INSERT	4
10	150731	WATER OUTLET PLUG	2
11	10280060	GASKET	2
12	13544024	STUD	2
13	14325140	THREADED PLUG	1
14	13543424	STUD	5
15	10275011	THREADED PLUG	3
16	10263460	GASKET	3
17	13544024	STUD	1
18	13525870	THREADED INSERT	3
19	13525770	THREADED INSERT	1
20	164025	FRONT COVER	1
21	153921	GASKET	1
22	100041	DOWEL	2
23	13543624	STUD	1
24	12601374	WASHER	9
25	101139	NUT	9
26	13543524	STUD	6
27	12604474	WASHER	18
28	101139	NUT	18
29	13517224	STUD	3
30	133628	GASKET	1
30	163985	GASKET	1
31	13543324	STUD	11
32	13543524	STUD	1
33	16043834	SCREW	2
34	11198074	WASHER	2

## 001 Crankcase

35	13544324	STUD	1
36	102725	DOWEL	2
37	13543524	STUD	3
38	13546624	STUD	6
39	159955	ENGINE FIXING SUPPORT	2
40	11190574	WASHER	6
41	133988	NUT	6
42	15970634	SCREW	8
43	127497	WASHER	8
44	14496624	WASHER	8
45	13516624	STUD	4
46	162373	UPPER SPACER	2
47	162769	WICK BODY	2
48	162375	LOWER SPACER	2
49	15864234	SCREW	2
50	12601774	WASHER	2
51	176573	NUT	2
52	104075	STUD	10
53	125317	DOWEL	10
54	164025	FRONT HAT	1
55	164025	FRONT INTERMEDIATE HAT	1
56	164025	INTERMEDIATE CENTRAL AND REAR HAT	2
57	164025	REAR HAT	1
58	103842	WASHER	10
59	6103841	NUT	10
60	164400	THREADED PLUG	2
61	12620474	WASHER	6
62	114748	NUT	6
63	13547135	STUD	4
64	13544024	STUD	2
65	156862	NONRETURN VALVE	2
66	156865	DOWEL (R.H. FRONT - L.H. REAR)	2
67	156864	DOWEL (L.H. FRONT - R.H. REAR)	2
68	142471	REAR COVER	1
69	13525570	THREADED INSERT	2
70	142472	O.R. GASKET	1
71	103038	DOWEL	2
72	13541124	STUD	2
73	13540824	STUD	4

001 Crankcase

74	171177 BEARING	2
74	171177 BEARING	2
75	169474 SENSOR FOR FIRING	2

ロッシオーグループ株式会社  
<https://www.rossoauto.com>