


010 Fuel Tank



<https://www.rosco.co.uk>, Ltd.

010 Fuel Tank

No.	Part No.	Name	Qty
1	165652	FUEL TANK	1
2	146648	FUEL LEVEL INDICATOR CONTROL	1
3	154802	GASKET	1
4	121435	RING NUT	1
5	135035	R.H. SUPPORT	1
6	135036	L.H. SUPPORT	1
7	125035	RUBBER THICKNESS	2
8	15970721	SCREW	4
9	127497	WASHER	4
10	14496624	WASHER	4
11	140745	SPACER WASHER MM. 2,0	16
11	140746	SPACER WASHER MM. 3,0	16
11	140747	SPACER WASHER MM. 4,0	16
12	127403	RUBBER THICKNESS	4
13	137994	ANTI-VIBRATION SUPPORT	2
14	102742	NUT	2
15	12644301	WASHER	2
16	153965	UNION	1
16	160719	UNION	1
17	174095	GASKET	1
18	180320	PLUG	1
18	180320G	PLUG	1
19	62926700	SCREW	3
20	12601274	WASHER	3
21	62943200	PLUG PROTECTION	1
22	141507	BRACKET	1
22	176214	BRACKET	1
23	14058511	NUT	1
24	15896211	NUT	2
25	141066	UNION-TANK CONNECTING PIPE	1
26	141033	GASKET	2
27	165398	COLLAR FOR SLEEVE	2
28	145855	CLAMP	2
29	125036	RUBBER THICKNESS	2
30	168374	SHIELD FOR TANK PROTECTION	1
31	102741	NUT	1
32	10519424	WASHER	1