


116 TopHydraulic -Valid Spider



<https://www.116tophydraulic.com/>

## 116 TopHydraulic -Valid Spider

No.	Part No.	Name	Qty
0	64418200	COMPLETE HYDRAULIC CIRCUIT	1
1	64967200	R.H. SECONDARY CYLINDER	1
2	65699800	L.H. SECONDARY CYLINDER	1
3	168857	(L) PIPE FROM VALVE TO PUMP	1
4	168858	(N) PIPE FROM VALVE TO PUMP	1
5	168859	(K) PIPE FROM VALVE TO L.H. MAIN CYLINDER	1
6	168860	(O) PIPE FROM VALVE TO R.H. SECONDARY CYLINDER	1
7	168861	(P) PIPE FROM VALVE TO R.H. SECONDARY CYLINDER	1
8	168862	(R) PIPE FROM VALVE TO L.H. SECONDARY CYLINDER	1
9	168863	(S) PIPE FROM VALVE TO L.H. SECONDARY CYLINDER	1
10	168864	(V) PIPE FROM PUMP TO R.H. MAIN CYLINDER	1
11	168865	90° UNION	1
12	168866	O.R. GASKET FOR UNIONS	1
13	141699	CLIP	8
14	64660200	ELECTRONIC CONTROL STATION	1
15	13833224	CONTROL STATION FIXING SCREW	2
16	13835814	BLOCKS FIXING SCREW	2
17	125242	15 A. FUSE	1
17	131941	30 A. FUSE	1
18	157992	RELAY	2
19	155184	BRACKET	2
20	177710	OR KIT + SCREWS	1
21	168881	CUP COMPLETE KIT	1
22	177713	SCREW FIXING VALVE TO PUMP	2
23	177712	HYDRAULIC PUMP VALVE	1
24	65730100	PUMP BRACKET	1
25	65699900	COMPLETE HYDRAULIC PUMP	1
26	177714	(W) PIPE ON THE HYDRAULIC PUMP	1
27	177715	(U) PIPE FROM PUMP VALVE TO R.H. MAIN CYLINDER	1
28	177716	(T) PIPE FROM PUMP VALVE TO L.H. MAIN CYLINDER	1
29	177802	UNION	1
30	177790	COMPLETE R.H. MAIN CYLINDER	1
31	177767	COMPLETE L.H. MAIN CYLINDER	1
32	177804	MAIN CYLINDERS WIRE	2
33	177803	L.H. SECONDARY CYLINDER WIRE	1
34	168884	SMALL PLATE FIXING SCREW	4
35	168885	SMALL PLATE	4
36	177711	SEEGER RING	1
37	14359021	SOLENOID VALVE FIXING SCREW	2

116 TopHydraulic -Valid Spider

38	168888 COMPLETE SOLENOID VALVE	1
39	64662600 SOLENOID VALVE FIXING SMALL PLATE	1
40	10794014 NUT	2
41	14496201 WASHER	2
42	168889 SPACER	2
43	168890 RUBBER BUSHING	2
44	168891 PUMP FIXING PLATE	1
45	14496424 WASHER	2
46	104030 NUT	2
47	MC4325/4 CLAMP	6
48	180424 SCREW	2

ロッシオーテック株式会社  
<https://www.rossoauto.com>